

C14 Swing Arm Slider Instructions



Parts List:

- 1 -Delrin Slider and Aluminum Spool Assembly
- 1-10x120 MM (Drive Shaft Side) of 1-10x100MM (Muffler Side) SHCS
- 1-10MM SS Flatwasher
- 1-SS 10 Self locking nut
- 1-ABS Hole Cover



Begin by removing the hole cover currently on the motorcycle, a thin flat blade screw driver works well, slowly work your way around the plug and pop it out.



Leave the mounting bolt in the slider assembly and slide through the now showing hole.

Install the flat washer followed by the lock nut, hold the nut requires a 14MM wrench while the SHCS requires a 8MM Hex key. The official torque spec is 18 Ft Lbs, but as tight as you can get it with hand tools works well too. Once the hardware is tight, install the ABS hole cover over the end.